

【產品】 F30 INDASH LCD 螢幕顯示器 螢幕尺寸 12.3 吋

系統 : 螢幕顯示器 **Linux** . 螢幕顯示器 螢幕

.720*1920 螢幕尺寸 12.3 吋 螢幕顯示器 螢幕顯示器 螢幕 : 螢幕顯示器

螢幕顯示器: **T507 plus (CPU4 core_primary.**(螢幕顯示器 螢幕尺寸 **1.8** 吋)

.(螢幕顯示器) 螢幕顯示器 4 (螢幕顯示器) 螢幕顯示器 1 : 螢幕顯示器

. 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器

. 螢幕顯示器 螢幕 12 吋 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕 4 吋

螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器 螢幕顯示器.





Instrument Installation Steps

1

Step

Adjust the steering wheel to the lowest position and hook the second hole above the original instrument panel with a tool. Pull down the iron plate from the second to last hole and remove the original instrument panel.



2

Step

Remove the iron plate from the original instrument panel and install it on the new instrument panel machine. Insert the corresponding plug wires in pairs.



1. USB interface (for upgrading instruments)
2. Original vehicle instrument power line interface
3. Original vehicle instrument fiber optic interface (note: 3 series does not have this interface)

Accessory

1. Loading tool (note: 3 Series does not have this accessory)
2. USB (for upgrading instruments)

