

BWM M3 F20 F21 F40 F22 F23 F45 F44 F30 F31 F35 F32 F33 F36 □□□□ □ □□ □□□

M3□ □□□ □□□□□.

(1 □□□ F20/F21/F40)

(2 □□□ F22/F23/F45/F44)

(3 □□□ F30/F31/F35)

(4 □□□ F32/F33/F36)

(X1 F48/F49) (X2 F39) (X3 F25) (X4 F26) (X5 F15) (X6 F16) (3 □□□ GT F34)

(M2 F87) (M3 F80) (M4 F82/F83)

M5 □□ :

(5 □□□ F10/F11)

(6 □□□ F06/ F12/ F13)

(7 □□□ F01/F02/F03)

(5 □□□ GT F07)) (M5F10/F90) (M6 F06/F12/13) (M8 F91/F92/F93)